



# Industrial Sewing Machine AC Servo Control System Operation Instruction

## 1. Introduction

**1.1 Abstract**  
Industrial sewing machine servo control system adopts new mechanical design with small volume, compact structure, beautiful shape and installation flexibility. Its circuit design isolates the driver and main control, and so prevents the control circuit from interference of driver. Finally, it has the excellence stability and reliability. With optimized SMPS designation, it archives the good efficiency and lower consumption with lower heat. The system has the perfect protective circuits which prevent it from burned circuit because of short circuit of power supply. The system, with built-in advanced algorithm, has the higher precision and faster response time. It is designed with feasible method to adjust the needle stop position which cuts down the time to fix the needle position and facilitates the debugging and installation of the machine.

## 1.2 Composition

Servo control system consists of the following parts:

1. Main parts: Servo control cabinet, operation panel, pedal controller, permanent magnet AC servo motor.
2. Accessories: stand of operation panel, user manual, power supply cable, pedal connecting rod, screws.

Please check the packed parts according the packing list at the first time opening the carton, if any lack, contact the distributor asap.


## 1.3 Technology Specification

Parameter	Specification
Rated input voltage	220V±10%
Rated input frequency	50/60HZ
Rated output power	750W
Maximum motor rotation speed	5000rpm
Maximum output torque	3.5Nm

Item	Name	Unit	Qty.
1	Servo control cabinet	pcs	1
2	Operation panel	pcs	1
3	Pedal controller	pcs	1
4	permanent magnet AC servo motor	pcs	1
5	Stand of operation panels	pcs	1
6	User manual	book	1
7	Power supply cable	pcs	1
8	Pedal connecting rod	set	1
9	screw	bag	1

## 2. Operation description

### 2.1 Panel description



Panel keypad Panel LCD

Function	Key	Description	Icon on LCD
Function parameter edit	[P]	Enter function parameter edit mode after pressing the key for 2'S in the operation mode. Key function parameter edit mode after press the key for 2'S in the edit mode.	—
Setting parameter check and save	[S]	After setting the function code, press this key to check the present parameter and then can edit the parameter accordingly. When the parameter is fixed, press this key to save the setting and quit.	—
Speed increase/decrease	[▲/▼]	Increase the sewing speed. Slow down the sewing speed.	—
Parameter increase/decrease	[+/-]	Increase the parameter. Decrease the parameter.	—
Stitch setting	[S]	Press this key to change the line setting.	—
Auto function	[A]	Automatic function for constant stitch sewing.	—
Needle stop position selection	[N]	Set needle up/down stop position. The default is up position when the related icon is lighting on the panel LCD.	—
Slow launch setting	[L]	Set slow launch function. When the related icon is display on the panel, the function is activated.	—
Auto lift presser foot after pause	[L]	Set presser foot auto-lifting after pause function. When the related icon is display on the panel, the function is activated.	—
Auto lift presser foot after trimming	[L]	Set presser foot auto-lifting after trimming function. When the related icon is display on the panel, the function is activated.	—
Consecutive reverse sewing	[R]	Set consecutive reverse sewing function. When the related icon is display on the panel, the function is activated.	—
Sewing as you please	[Y]	Set sewing as you please function. When the related icon is display on the panel, the function is activated.	—
Start back-tracking sewing	[B]	Set start single back-tracking sewing function, and its section AB or B parameter. When the an icon is display on the panel, the related function is activated.	—
End back-tracking sewing	[E]	Set end dual back-tracking sewing function. When the related icon is display on the panel, the function is activated.	—
Constant stitch sewing	[C]	Execute section E constant stitch sewing.	—
Line trimming	[T]	When this function is selected, and this icon will be displayed on the panel LCD, and so line trimming function is activated.	—
Lift and fill needle	[L]	Actuate lift and fill needle function	—
Speed display	[D]	Display the sewing speed grade	—

## 2.2 Operation mode selection

### 2.2.1 Sewing mode

The machine enters into sewing mode as default setting after powering on. In the sewing mode, the user can select various kinds of sewing function by setting technology parameter. In sewing mode, the users can switch between various kinds of sewing function according to their need, but can't modify and set all the system technology parameters.

## 2.3 Functions operation

- ### 2.3.1 Back-tracking sewing function
- Check start back-tracking sewing steps as following:
1. Press the related key to set starts back-tracking sewing. When press the key consecutively, and it will set as (1) start back-tracking sewing, (2) section B setting, (3) section E setting, (4) section G setting, (5) section H setting.
  2. Adjust the stitches for section A and B by pressing +/-, and the number of stitches can be set between 0 and 15.
  3. End back-tracking sewing, start back-tracking dual sewing, end back-track dual sewing can be operated according the above steps.
- ### 2.3.2 Sewing as you please
1. Press sewing as you please function key to activate the function.
  2. The related icon is displayed on the panel to enter setting ok sewing as you please function.
  3. After setting ok, push the pedal to execute the sewing as you please.
- ### 2.3.3 Constant stitch sewing
- One section mode:**
1. Press one section constant stitch sewing function key to activate one section sewing.
  2. The related icon is lighting on the panel to hint setting ok one section mode. In the same time, press +/- to set stitches of section E which range from 0 to 999, push the front part of the pedal to execute one section sewing function and the machine will finish the section E sewing as set.
- Four section sewing mode:**
1. Press four section sewing function key to activate four section sewing.
  2. The related icon is lighting on the panel to hint four section sewing mode setting ok, then press +/- to set the number of section E and F stitches respectively which range from 0 to 99.
  3. Press stitch selection function key to change to interface where to set the number of section G and H stitches which ranges from 0 to 99.
  4. After change to the section G and H setting interface, press +/- to set the number of section G and H stitches which ranges from 0 to 99.
- After setting four sections sewing function, the machine will execute four section sewing and complete section E, F, G, H sewing when push the front part of the pedal.

- ### Seven section sewing mode:
1. Press four section sewing function key continuously until seven section sewing icon is display.
  2. The related icon is lighting on the panel to hint seven section sewing mode setting ok, then press +/- to set the number of section E and F stitches respectively which range from 0 to 99.
  3. Press stitch selection function key to change to interface where to set the number of section G and H stitches which ranges from 0 to 99.
  4. After change to the section G and H setting interface, press +/- to set the number of section G and H stitches which ranges from 0 to 99.
- After setting seven sections sewing function, the machine will execute four section sewing and complete section E, F, G, H sewing when push the front part of the pedal.

- ### User-defined multi-section sewing mode:
1. Press four section sewing function key continuously until user-defined multi-section sewing icon is display.
  2. When user-defined multi-section sewing icon is lighting on the panel, and it hint the related function is set ok, in the same time, P.XXX is displayed on the panel which PX is standing for section No. (in HEX) and XXX for the number of stitches(in DEC).
  3. When user-defined multi-section sewing icon is lighting on the panel, and it hint the related function is set ok, in the same time, P.XXX is displayed on the panel which PX is standing for section No. (in HEX) and XXX for the number of stitches(in DEC).
  4. After setting user-defined multi-section sewing function, the machine will execute user-defined multi-section sewing and complete the set sections sewing when push the front part of the pedal.
  5. The number of section No. is indicated in HEX, and it ranges from P1 to P9 which adds up to 15 sections.
  6. The number of section stitches is indicated in DEC, and it ranges from 0 to 999.

- ### 2.3.4 Thread trimming function
1. Press thread trimming function to open or close the related function.
  2. The icon will be lighted on the panel when the function is open, and the icon disappears when the function is closed.

- ### 2.3.5 Presser auto lifting function after trimming
1. Push presser auto lifting after trimming function key to open or close presser auto lifting function.
  2. When the function is open, the related icon will be lighted on the panel; and the icon disappears when closed.

- ### 2.3.6 Press auto lifting function when pause
1. Push presser auto lifting when pause trimming function key to open or close presser auto lifting function.
  2. When the function is open, the related icon will be lighted on the panel; and the icon disappears when closed.

- ### 2.3.7 Needle stop position selection function
1. Press the function key to set needle stop on the up position or down position.
  2. When the up position is selected, the icon is lighted on the panel; the icon will disappear when down position is selected, the stop position is system default setting, and the icon is lighted on the panel. When the icon is not on the panel, down stop position is set.

## 2.2 User parameter setting mode

In user parameter setting mode, users can adjust various kinds of sewing function parameter. It can be set as the following steps:

1. Press key P for 2'S in the sewing mode to Enter into user parameter setting mode.
2. Press +/- to select the required function ID.
3. Press key S to check and modify the related parameter. Press +/- to set the required parameter.
4. After fixing the parameter, press key S to save the setting and quit the interface.
5. Press key P for 2~3S to quit the user parameter setting mode and recovery to sewing mode.

Items	Default	Range	Contents
Fn-01	Minimum sewing speed (r/min)	5000	Minimum speed adjustment
Fn-02	Set accelerated curve (Q)	80	Set the acceleration slope
Fn-03	Start Back-Tacking Speed (r/min)	1800	Set Start Back-Tacking Speed
Fn-04	End Back-Tacking Speed (r/min)	150	Set End Back-Tacking speed
Fn-05	Bar-Tacking Speed (r/min)	1800	Set Bar-Tacking speed
Fn-06	Slow Start Speed (r/min)	300	Set slow start speed
Fn-07	Number Of Stitches For Slow Start	2	Number of stitches setting for slow start
Fn-08	Automatic Constant-Stitch Sewing Speed (r/min)	3200	Speed adjustment for automatic constant-stitch sewing
Fn-09	Automatic End Back-Tacking sewing	1	1: After last seam of Constant Stitch sewing, it will automatic execute the End Back-Tacking sewing. When turned on, the Stitch-Correction is enable. 0: Automatic End Back-Tacking will not execute after last seam, but can be done by pedal manually.
Fn-10	Back-Tacking Mode selection	1	0: BROTHER mode (Back-tacking sewing is executed whenever machine is stopped or paused). 1: AUTOMATIC mode (Back-tacking sewing is executed when machine is running, needle filling is executed then stop).
Fn-11	Start Back-Tacking Running Mode selection	1	0: Automatically perform actions 1: Could be arbitrarily stop and start.
Fn-12	Ending Mode Of Star Back-Tacking	1	0: After the number of stitches is completed, the action stop automatically. 1: Start Back-Tacking is completed automatically continued for next actions. 0: After the number of stitches is completed, the action stop automatically.
Fn-13	Start Back-Tacking compensation -1	60	Compensation for A part of Start Back-Tacking
Fn-14	Start Back-Tacking compensation -2	60	Compensation for B part of Start Back-Tacking
Fn-15	End Back-Tacking Running Mode selection	1	0: Automatically perform actions 1: Could be arbitrarily stop and start.
Fn-16	End Back-Tacking compensation -1	60	Compensation for C part of end Back-Tacking
Fn-17	End Back-Tacking compensation -2	60	Compensation for D part of end Back-Tacking
Fn-18	Bar-Tacking Running Mode selection	1	0: Automatically perform actions 1: Could be arbitrarily stop and start.
Fn-19	Bar-Tacking compensation -1	60	Compensation for A part of Bar-Tacking
Fn-20	Bar-Tacking compensation -2	60	Compensation for B part of Bar-Tacking
Fn-21	Needle stop Position Selection	1	Valid only when the operation panel is disconnected, (1)UP / 0 (DOWN)
Fn-22	Slow Start Function Selection	0	Valid only when the operation panel is disconnected, (1)ON / 0 (OFF)
Fn-23	Automatic Foot Lift After Trimming Function Selection	0	Valid only when the operation panel is disconnected, (1)ON / 0 (OFF)
Fn-24	Automatic Foot Lift When Pause	0	Valid only when the operation panel is disconnected, (1)ON / 0 (OFF)
Fn-25	Automatic Function Selection	0	Valid only when the operation panel is disconnected, (1)ON / 0 (OFF)

## 2.3.8 Lifting and filling the needle function

1. When the function is set under sewing as you please mode, the machine will execute needle lifting or half-stitch filling.
2. When the function is set under constant stitch sewing, and the machine will execute needle lifting while press the function at the moment of the machine is paused.
3. If the function key is pressed while finished such section sewing, the machine will execute needle filling function.

## 2.3.9 Consecutive back-tracking sewing function

1. Press the related key to open the function. The icon will be lighted.
  2. In the same time the repeat turn E setting interface is displayed on the panel, then press +/- to adjust the number, which ranges from 1 to 999.
  3. Press stitch selection function key to enter into section A,B,C,D stitch setting interface.
  4. After setting the consecutive back-tracking sewing function, push the front part of the pedal to complete the consecutive backtracking sewing, the repeat turn is fixed by parameter E.
- Once the function is activated, the machine will not stop until completing all the steps of consecutive back-tracking sewing. The machine will stop as soon as the rear part of the pedal is pushed during sewing and the set consecutive back-tracking will be completed.

## 2.3.10 Slow start function

1. Press the related key to open or close the function. The related icon is lighted when open, disappeared when close.
2. When slow start function is opened, the machine will start slowly to sewing the start stitches while the front part of the pedal is pushed, and then operate normally.

## 2.3.11 Stitch tracking remedial measure

The following description is based on A=4, B=4 for dual start back-tracking sewing remediation:

Issue description	Remedial measure
	The stitch number of section A is beyond the set value, or the length of section A last stitch is increased, the length of section B first stitch increased, which cause the final stitch of B can't overlap with the initial stitch of section A. Measure: Turn up the parameter of Fn-13 properly.
	The stitch number of section A is less than the set value, or the length of the section A last stitch is decreased, the length of section B first stitch decreased, which cause the final stitch of section B is over the initial stitch of section A. Measure: Turn down the parameter of Fn-13 properly.
	The stitch number of section B is beyond the set value, or the length of the section B last stitch is increased, the length of following section first stitch decreased, which cause the final stitch of section B is over the initial stitch of section A. Measure: Turn up the parameter of Fn-14 properly.
	The stitch number of section B is less than the set value, or the length of the section B last stitch is decreased, the length of following section first stitch increased, which cause the final stitch of section B can't overlap with the initial stitch of section A. Measure: Turn down the parameter of Fn-14 properly.

## 3. Auxiliary function

### 3.1 Needle up stop position

- #### 3.1.1 Digital mode
- When Fn-81=1, needle positioning mode setting method is digital mode, as follow:
- (Note: In digital mode, the first time using machine as well as the replacement of equipment is required reset the position.)
1. Long press key S, in the same time turn on the power switch from off to enter into special function setting mode. Press +/- to select the required function ID.
  2. Set the function ID as 8880, and enter into needle up stop position setting.
  3. Rotate the hand wheel to adjust the needle to the up stop position.
  4. After adjustment, press S to save the setting. In this time, four short tones is heard and hint finishing the setting. The position adjusted in the fore step is the set up stop position. Repeat the fore step to set the suitable position.

Fn-26	Ripe Thread Function / Clamp Thread Function Selection	1	0-2	0 (OFF) 1 (Ripe Thread Function ON) 2 (Clamp Thread Function ON)
Fn-27	Clamp start angle	180	1-360	Clamp start angle
Fn-28	Clamp release angle	300	30-330	Clamp release angle (Thread length control)
Fn-36	Reverse needle lifting angle	0	0-2	0FF(0)ON(1)/Lifted switch (2)
Fn-37	Reverse needle lifting angle	40	20-80	Reverse needle lifting angle
Fn-38	Pedal stroke ratio (%)	100	30-100	Pedal stroke ratio (%)
Fn-39	Finished Sewing Piece Counter	0-9999		Display the quantity of finished sewing piece

## 2.2.3 System parameter setting mode

In system parameter setting mode, it's available to adjust kinds of the parameter of the electromagnets and system setting. Details parameter can be set according the following steps.

1. Long press key F, in the same time turn on the power. Switch from off to enter into system parameter setting mode. In this mode, both system parameter and user parameter can be modified.
2. Press +/- to select the required function ID, press key S to enter parameter modification interface to check and modify the parameter.
3. After fix the parameter, press key S to save the setting and quit.
4. Long press key P for 2'S to quit the system parameter setting mode and recovery to normal sewing mode.

## System parameter table

No.	Items	Default	Range	Contents
Fn-40	Direction of Motor Rotation	—	—	Reserved
Fn-41	Motor Brake Function	0	0-1	1: When motor stopped, keep it locked / 0, No effect 0: disable
Fn-42	Auto running for test function	0	0-1	When the parameter set as 1, the machine will start auto running as sewing function set on the operation panel.
Fn-43	Motor auto-running full time (hr.)	8	1-800	Only valid when Fn-42=1, set the full time for motor auto-running
Fn-44	Motor auto-running on cycle time (hr.)	3	1-30	Only valid when Fn-42=1, set the motor on time for each running cycle.
Fn-45	Motor auto-running off cycle time (hr.)	3	1-60	Only valid when Fn-42=1, set the motor off time for each running cycle.
Fn-46	The minimum speed (r/min)	200	100-500	Adjust the minimum speed of the motor
Fn-47	Thread training speed (r/min)	300	100-500	Speed is too low may lead to unusual thread, the speed is too high may lead to unstable positioning control.
Fn-48	Foot lifter and back-tracking rise/electromagnet operation time to full output (ms)	300	0-990	Foot lifter and back-tracking electromagnet operation time to full output
Fn-49	Back-tracking electromagnet operation duty cycle (%)	30	10-90	Back-tracking electromagnet operate in duty cycle to save the electricity and protect the electromagnet from over-heat.
Fn-50	Motor starting delay time (ms)	50	0-990	Delay the start time, with automatic presser foot down.
Fn-51	Half step pulse from lift	1	0-1	1: ON / 0: OFF
Fn-52	Safety switch signal selection	0	0-1	1: Keep OFF / 0: Keep OFF
Fn-53	Trimming operation delay before the mechanical angle (degrees)	189	120-250	The degrees between IP position and thread training action
Fn-54	Completion of the thread trimming action required (degrees)	360	250-360	Completion of the mechanical angle of the thread trimming action required
Fn-55	Thread take action before the delay time (ms)	10	0-980	The time between IP position and Thread take action
Fn-56	Thread take action time (ms)	70	0-9990	Completion of the thread take up action required time

## 3.1.2 Magnet steel mode

When Fn-81=1, needle positioning mode setting method is magnet steel mode, as follow:

(Note: In magnetic mode, on the needle position is set up, as long as the hand wheel, motor is not disassembled, moved, the needle position no need to be reset.)

1. Power on, observe the needle position, by adjusting the magnetic steel adjusting screw on the hand wheel, adjusting the needle position.
2. Step on the foot pedal, observe the needle a needle stop position.
3. Adjustment of needle position until it reaches the requirement of users.

## 3.2 Parameter copy and paste function

1. Long press key S, in the same time turn on the power switch from off to enter into special function setting mode. Press +/- to select the required function ID.
  2. Set the function ID as 001 to enter into copy and paste function
  3. Press auto function key to execute copy and paste function, which mean copy the parameters saved in panel memory and paste them to main controller memory assembly.
- Press line trimming function key to copy the parameters in main controller memory to panel parameter memory.

## 3.3 Factory parameter initialization

1. Refer to section 2.2.1 to enter into system parameter setting mode.
2. Set function ID and into Fn-79 Parameter, code input interface display on the panel.
3. Set different code to execute factory parameter initialization in different way. Details refer to the right table.

## 3.4 The number of processing statistics

Under sewing mode, press S key, the display will show the processing statistics for the number.

## 3.5 Real-time motor speed monitor

Under user parameter setting mode or system parameter setting mode, press the accelerate adjustment key [▲], the display will show the real-time speed of motor.

## 4. Troubleshooting and maintenance

When there is error in the system, the error information will display the panel, in the same time, the indicator led will light red. The user can handle the error by the error code according the manual. If the error can't be settled, please contact our technical support. Error code will be indicated in HEX on the panel. Refer to the following picture for Err-1 display:

Error code	Problem description	Measure
Err-0	Input signal self test error (power on fault detect)	1. Check the connectivity of pedal signal. 2. Release the pedal to neutral position.
Err-2	EPPROM read/write data error	Replace EPPROM
Err-3	EPPROM full-in-parameter error	Power-on reset
Err-4	Over-current, over-voltage, over-heat, low-voltage	1. Turn off the machine for at least 30S, then restart. 2. There may be some malfunction for the motor control module. 3. Check whether there are transient interference.
Err-5	Detect high voltage on the DC bus	1. Turn off the machine for at least 30S, then restart. 2. Check the power supply voltage.
Err-6	Detect over current for the power supply for electromagnet	1. Turn off the machine, and check the connectivity of the electromagnet circuit. 2. Turn off the machine and check the mechanical parts.
Err-7	Stalling	Turn the motor output signal line whether there is broken or poor contact.
Err-8	Motor decoder output signal error	1. Turn off the machine, and check the connectivity of synchronizer. 2. Replace synchronizer
Err-9	Synchronizer self test error	1. Turn off the machine, and check the connectivity of synchronizer. 2. Replace synchronizer
Err-E	Machine (head) maintenance prompt	The operation time reaches the maintenance period. Please do maintenance for the head, and then enter Fn-67 to reset the accumulated operation time.
Err-F	Safety switch alarming	1. Check whether the head of the machine is turned over. 2. Check the connectivity of the circuit of safety switch.

Note ① Description of the contents of Fn-75

Parameter monitoring

Different spots-light represents a different meaning.

The following table show below:

[01]	[02]	[03]	[04]	[05]
Pedal Forward signal input	Pedal backward signal input	Back-Tacking control switch input	The safety control switch input	(OPTION) UP position input
(OPTION) UP position input	(OPTION) DOWN position input	(Hall) (U) signal	(Hall) (V) signal	(Hall) (W) signal
(Hall) (U) signal	(Hall) (V) signal	(Hall) (W) signal	Bus voltage 1-5v high signal	Encoder (Z) signal
[10]	[11]	[12]		